

DESCRIPTION	YEAR	PART NUMBER	QTY	REF#/NOTES
KITS				
MASTER KIT W/CLUTCHES & STEELS	1958	FP102-1	1	
MASTER KIT W/CLUTCHES & STEELS	1959	FP102A-1	1	
MAJOR KIT W/CLUTCHES	1958	FP102-2	1	
MAJOR KIT W/CLUTCHES	1959	FP102A-2	1	
OVERHAUL KIT	1958	FP102-3	1	
OVERHAUL KIT	1959	FP102A-3	1	
GASKETS				
PAN GASKET	1958-1959	D29-2	1	
SEALS				
FRONT PUMP SEAL	1958-1959	D4-9	1	
BUSHINGS				
BUSHING KIT	1958	KFP106	1	
BUSHING KIT	1959	KFP106A	1	
NEW HARD PARTS				
TORQUE BALL SEAL KIT	1958-1959	D110-9C	1	
REBUILT & USED HARD PARTS				
FRONT PUMP ASSEMBLY	1958	FP01	1	SEALING RING
FRONT PUMP ASSEMBLY	1959	FP01A	1	LIP SEAL
FRON PUMP BODY & GEARS	1958-1959	FP02	1	
FRONT PUMP STATOR	1958	FP03	1	SEALING RING
FRONT PUMP STATOR	1959	FP03A	1	LIP SEAL
NEUTRAL CLUTCH DRUM	1958-1959	FP05	1	
FORWARD CLUTCH DRUM	1958-1959	FP06	1	
REVERSE CLUTCH DRUM	1958-1959	FP07	1	
HILL BRAKE DRUM	1958-1959	FP08	1	
FRONT PLANETARY	1958-1959	FP10	1	
FRONT PLANETARY	1958-1959	FP10A	1	
REAR PLANETARY	1958-1959	FP11	1	
FRONT PLANETARY RING GEAR	1958-1959	FP13	1	
REAR PLANETARY RING GEAR	1958-1959	FP14	1	
FRONT SUN GEAR	1958-1959	FP19	1	
SUN GEAR	1958-1959	FP20	1	
INPUT SHAFT	1958-1959	FP25	1	
CENTER SUPPORT	1958	FP28	1	SEALING RING

CENTER SUPPORT	1959	FP28A	1	LIP SEAL
VALVE BODY	1958	FP33	1	
VALVE BODY	1959	FP33A	1	
SPRAG	1958-1959	FP35	1	
SPRAG	1958-1959	FP35A	1	
TRANSMISSION CASE	1958-1959	FP36	1	
EXTENSION HOUSING	1958-1959	FP37	1	
FORWARD PISTON	1958-1959	FP39	1	
NEUTRAL PISTON	1958-1959	FP40	1	
REVERSE PISTON	1958-1959	FP41	1	
REVERSE CLUTCH PRESSURE PLATE	1958-1959	FP44	1	
NEUTRAL PRESSURE PLATE	1958-1959	FP44A	1	TOP
NEUTRAL PRESSURE PLATE	1958-1959	FP45	1	BOTTOM
NEUTRAL SPACER CUSHION	1958-1959	FP45A	1	
INNER SPRAG RACE	1958-1959	FP46	1	
OUTER SPRAG RACE	1958-1959	FP46A	1	
PARKING GEAR	1958-1959	FP47	1	
TRANSMISSION PAN	1958-1959	FP48	1	
OUTPUT SHAFT	1958-1959	FP52	1	
NEUTRAL CLUTCH HUB	1958-1959	FP59	1	
HILL BRAKE CLUTCH HUB	1958-1959	FP59A	1	
REAR PUMP	1958-1959	FP60	1	
PARKING PAWL	1958-1959	FP62	1	1180020
RANGE LEVER	1958-1959	FP63	1	
HILL BRAKE PISTON	1958-1959	FP76	1	
FLYWHEEL COVER	1958-1959	FP109B	1	
FIRST TURBINE HUB	1958-1959	FP109C	1	
SECOND TURBINE	1958-1959	FP109D	1	
THIRD TURBINE	1958-1959	FP109E	1	
FIRST TURBINE	1958-1959	FP109F	1	