

DESCRIPTION	YEAR	PART NUMBER	QTY	REF#/NOTES
KITS				
MASTER KIT W/CLUTCHES & STEELS	1966-1978	164-LX	1	
MAJOR KIT W/CLUTCHES	1966-1978	264-LX	1	
OVERHAUL KIT	1966-1978	340-LX	1	
GASKETS				
PAN GASKET	1966-1978	2586L	1	
SPROCKET COVER GASKET	1966-1978	2584L	1	
DIFFERENTIAL TO CASE GASKET	1966-1978	2580L	1	
FILTER				
TRANSMISSION FILTER	1966-1978	858L	1	
O-RINGS				
FILLER TUBE O-RING	1966-1978	4702BC	1	
SEALS				
FRONT PUMP SEAL	1966-1978	3178E	1	
MANUAL LEVER SEAL	1966-1978	3179L	1	
LEFT AXLE SEAL, EXCEPT BELOW	1966-1978	404400	1	3-3/16"
LEFT AXLE SEAL – OLDSMOBILE TORONADO	1966-1967	391297	1	
RIGHT AXLE SEAL, EXCEPT BELOW	1966-1978	397470	1	2-3/8"
RIGHT AXLE SEAL – OLDSMOBILE TORONADO	1966-1967	391296	1	
PINION SEAL	1966-1978	1371622	2	
BANDS				
FRONT BAND	1966-1978	BT-50	1	
REVERSE BAND	1966-1978	BT-84N	1	NEW
MODULATOR				
BLACK CAN MODULATOR	1966-1972	MT-93	1	
BLACK CAN MODULATOR	1973-1978	MT-52	1	
BRASS CAN MODULATOR	1966-1978	MT-56	1	
RED STRIPE MODULATOR	1966-1978	MT-23	1	
FRICTIONS				
FORWARD FRICTION	1966-1978	1225L	5	
DIRECT FRICTION	1966-1978	1225L	5-6	
INTERMEDIATE FRICTION	1966-1978	1226L	3	

STEELS				
FORWARD STEEL PLATE	1966-1978	1239L	4	
DIRECT STEEL PLATE	1966-1978	1253L	4-5	
INTERMEDIATE STEEL PLATE	1966-1978	1237L	3	
BUSHINGS				
BUSHING KIT	1966-1978	5047-LX	1	
PUMP BUSHING	1966-1978	5295L	1	
WASHERS				
THRUST WASHER KIT	1966-1978	6072-LX	1	
BEARING KIT	1966-1978	6699-LX	1	3 Piece Set
SEALING RINGS				
SEALING RING KIT	1966-1978	7067-LX	1	
NEW HARD PARTS				
SOLENOID PASS THROUGH CONNECTOR	1966-1967	8167E	1	2 PRONG - VP
SOLENOID PASS THROUGH CONNECTOR	1968-1978	9295L	1	1 PRONG
SOLENOID PASS THROUGH CONNECTOR	1970-1978	9296L	1	2 PRONG
DETENT SOLENOID	1966-1978	8162L	1	
VARIABLE PITCH SOLENOID	1966-1967	8169E	1	
INTERMEDIATE SPRAG - ELEMENT	1966-1970	9534L	1	
INTERMEDIATE SPRAG – SPRING & ROLLER	1970-1978	8154L	1	
LOW SPRAG – ELEMENT TYPE	1964-1966	8126L	1	
LOW SPRAG – SPRING & ROLLER	1966-1978	8131L	1	
GOVERNOR GEAR	1966-1978	8406L	1	
DRIVE CHAIN	1966-1978	N/A	1	
REBUILT / USED HARD PARTS				
PUMP BODY & GEARS	1966-1978	425-02	1	
VARIABLE PITCH STATOR	1966-1967	425-03	1	
NON-VARIABLE PITCH STATOR	1968-1978	425-03A	1	
DIRECT DRUM	1966-1978	425-05	1	
FORWARD DRUM W/VARIABLE PITCH	1966-1967	425-06	1	
FORWARD DRUM	1968-1978	425-06A	1	
FRONT PLANETARY	1966-1978	425-10	1	
REAR PLANETARY	1966-1978	425-11	1	
REAR PLANETARY RING GEAR	1966-1978	425-14	1	
SUN GEAR	1966-1978	425-20	1	
DRIVEN SPROCKET	1966-1978	425-23	1	
DRIVE SPROCKET – VARIABLE PITCH	1966-1967	425-24	1	
DRIVE SPROCKET – NON-VARIABLE PITCH	1968-1978	425-24A	1	
DRIVEN SPROCKET SUPPORT	1966-1978	425-27	1	

CENTER SUPPORT	1966-1978	425-28	1	
GOVERNOR ASSEMBLY	1966-1978	425-32	1	
VALVE BODY W/VARIABLE PITCH	1966-1967	425-33	1	
VALVE BODY, NON - VARIABLE PITCH	1968-1978	425-33A	1	
TRANSMISSION CASE – OLDSMOBILE	1966-1978	425-36	1	
TRANSMISSION CASE - CADILLAC	1966-1978	425-36A	1	
FORWARD CLUTCH PISTON	1966-1978	425-39	1	
TRANSMISSION OIL PAN	1966-1978	425-48	1	
TRANSMISSION SIDE PAN	1966-1978	425-48A	1	
DRIVE CHAIN	1966-1978	425-53	1	USED
OUTPUT FLANGE	1966-1978	425-59	1	
FORWARD CLUTCH HUB	1966-1978	425-59A	1	
DIRECT CLUTCH HUB	1966-1978	425-59B	1	
CHANNEL PLATE – 8625009	1966-1978	425-61	1	
CHANNEL PLATE - 8627897	1966-1978	425-61A	1	
MANUAL LEVER SHAFT	1966-1978	425-67	1	
MAIN SHAFT	1966-1978	425-80	1	
TORQUE CONVERTER				
VARIABLE PITCH TORQUE CONVERTER	1966-1967	B2	1	R&R ONLY
NON-VP TORQUE CONVERTER	1968-1978	B3	1	